

Derek Barbosa, Peter Wallace
Professor Herbordt: EC 413
Oct 30th 2020

Lab 5: Pipeline Datapath

Datapath and Timing Diagrams

Description

We built our own datapath from the ground up. We initialized the three stage registers and “piped” each output according to the diagram given (see Lab 5 Manual).

To test our datapath, we utilized the I-type and R-type instructions provided to us from the Lab Manual and other sample test benches (see the .tb file).

```
#30
InstrIn= 32'b011010_00000_00000_000000000000101;          // I, add r0 with 00000005 =>  r0 = 00000005

#10
InstrIn= 32'b011010_00001_00001_0000000000001010;          // I, add r1 with 0000000A =>  r1 = 0000000A

#10
InstrIn= 32'b011010_00010_00010_1111111111111000;          // I, add r2 with 0000FFFF =>  r2 = 0000FFFF

#10
InstrIn= 32'b011001_00011_00011_1111111111111000;          // I, not r3                                =>  r3 = FFFFFFFF^M
^M
#10
InstrIn= 32'b011100_00100_00100_1010101010101010;          // I, or r4 with 0000AAAA  =>  r4 = 00000AAAA^M
^M
#10
InstrIn= 32'b011101_00101_00101_1111111111111111;          // I, and r5 with 0000FFFF =>  r5 = 00000000^M
^M
#10
InstrIn= 32'b011110_00110_00110_1111111111111000;          // I, slt r6 with 0000FFFF =>  r6 = 00000001^M

---- R type ----
#10
InstrIn= 32'b010001_00111_00001_00000_000000000000;          // R, not r1(0000000A)                =>  r7 = FFFFFFF5

#10
InstrIn= 32'b010010_01000_00001_00010_000000000000;          // R, add r1(0000000A) with r2(0000FFFF) =>  r8 = 00010002^M
^M
#10
InstrIn= 32'b010010_01001_00001_00011_000000000000;          // R, add r1(0000000A) with r3(FFFFFFF) =>  r9 = 00000009^M
^M
#10
InstrIn= 32'b010010_01010_00001_00100_000000000000;          // R, add r1(0000000A) with r4(0000AAAA) =>  r10 = 0000AAB4^M
^M
#10
InstrIn= 32'b010010_01011_00001_00101_000000000000;          // R, add r1(0000000A) with r5(00000000) =>  r11 = 0000000A ^M
^M
#10
InstrIn= 32'b010010_01100_00001_00110_000000000000;          // R, add r1(0000000A) with r6(00000001) =>  r12 = 0000000B ^M
...
```

Some sample instructions

Waveforms









